


Schematic diagram of connection



Dipswitch explained



1 2 3 4 5

Definition of single display model keys




Control the media up and down

Increase system volume
Decrease system volume

Press and hold for 2 seconds to enter the system page
Short press back to the HOME page of the system

Voice awakening Answer call End call



Please select AUX mode before entering the system,
and then enter the system operation

Press and hold for 2 seconds to enter the system page
Short press back to the HOME page of the system

Knob controls system APP
Press to enter the APP function
Left dial and right dial controls media up and down
Dialing up and down controls the cursor to move up and down

Return to the previous level

Single displays



ILX (2013)



RDX (2013)



TL (2009 - 2012)



ILX (2015 - 2018)



TLX (2015 - 2019)



TLX-L (2018)



MDX (2009 - 2011)



ZDX (2012)



RLX (2013 - 2018)



RDX (2016)



RDX (2014 - 2017)

Double displays